



Optec, Inc.
Lowell, Michigan, USA

www.optecinc.com
Toll free: 888-488-0381

QuickSync Focus Motor Quick-Start

Basic instructions for installing your QuickSync FTX focus motor for FeatherTouch focusers.
Contact [Optec Support](#) for specific instructions for your motor or for additional details.



1 Remove Fine Focus Knob.



2 Remove Coarse Knob.



3 Slide Motor knob onto small shaft.
Clamp fits over stainless steel housing.



4 Tighten clamp - check Fine Focus movement.
Tighten Fine Focus Knob.



5 Test Motor—Rotate to Engage & Disengage



6 Connect USB & 12VDC Power

7 Download & Install FocusLynx
Version v3.1 driver.



Proudly Made in the U.S.A.